




Machine	Explode	Code	Description
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	1		Top Cover
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	2		Insulation
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	3		Toaster Top Cover
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	4		Back Panel
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	5		Main Body
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	6	AE663	Heating Element
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	7	AK552	Plug&Wire
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	8	AE664	Fixation
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	9		Insulation
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	10		Insulation Sheet
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	11		About Cover Plate
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	12	AE665	Cover Board
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	13	AE666	Switcch
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	14	AD585	Light
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	15	AN892	Timer
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	16		Dial
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	17	AE659	Crumb Tray
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	18	N287	Feet
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	19	AE658	Handle
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	20	AE657	Rack
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	21	AE660	Tray
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	22	AE667	Fixation 1
Buffalo Quartz Salamander Grill - 2.8kW (Bottom & Top)	23	AE668	Fixation 2

