




Machine	Explode	Code	Description
DC285 - Nisbets Essentials Mini Oven with Rotisserie	1		Glass Door
DC285 - Nisbets Essentials Mini Oven with Rotisserie	2		Outer Glass Plate
DC285 - Nisbets Essentials Mini Oven with Rotisserie	3		Spring Block
DC285 - Nisbets Essentials Mini Oven with Rotisserie	4		Left Door Axes Support
DC285 - Nisbets Essentials Mini Oven with Rotisserie	5		Door Axes
DC285 - Nisbets Essentials Mini Oven with Rotisserie	6		Pull Piece Hinge
DC285 - Nisbets Essentials Mini Oven with Rotisserie	7		Rear Door Frame
DC285 - Nisbets Essentials Mini Oven with Rotisserie	8		Right Support Bracket
DC285 - Nisbets Essentials Mini Oven with Rotisserie	9		Door Hook
DC285 - Nisbets Essentials Mini Oven with Rotisserie	10		Door Spring
DC285 - Nisbets Essentials Mini Oven with Rotisserie	11		Glass Door Inside
DC285 - Nisbets Essentials Mini Oven with Rotisserie	12		Indicator Cover
DC285 - Nisbets Essentials Mini Oven with Rotisserie	13,14	AL033	Knob
DC285 - Nisbets Essentials Mini Oven with Rotisserie	15	AL034	Plastic Control Panel
DC285 - Nisbets Essentials Mini Oven with Rotisserie	16	AL035	Thermostat
DC285 - Nisbets Essentials Mini Oven with Rotisserie	17	AL036	Timer
DC285 - Nisbets Essentials Mini Oven with Rotisserie	18	AL037	Switch
DC285 - Nisbets Essentials Mini Oven with Rotisserie	19	AL038	Power Board
DC285 - Nisbets Essentials Mini Oven with Rotisserie	20,21	AL039	Rubber Feet (set 4)
DC285 - Nisbets Essentials Mini Oven with Rotisserie	22		Bottom Enclosure
DC285 - Nisbets Essentials Mini Oven with Rotisserie	23		Stay-Pole
DC285 - Nisbets Essentials Mini Oven with Rotisserie	24,27	AL040	Fan Motor incl. Blade
DC285 - Nisbets Essentials Mini Oven with Rotisserie	25		Convection Cover
DC285 - Nisbets Essentials Mini Oven with Rotisserie	26		Transmission Axis
DC285 - Nisbets Essentials Mini Oven with Rotisserie	28	AL041	Lamp
DC285 - Nisbets Essentials Mini Oven with Rotisserie	29		Synchronous Motor Bracket
DC285 - Nisbets Essentials Mini Oven with Rotisserie	30		Synchronous Motor
DC285 - Nisbets Essentials Mini Oven with Rotisserie	31		Main Enclosure
DC285 - Nisbets Essentials Mini Oven with Rotisserie	32		DC Fan
DC285 - Nisbets Essentials Mini Oven with Rotisserie	33		Fan Frame
DC285 - Nisbets Essentials Mini Oven with Rotisserie	34		Rear Enclosure
DC285 - Nisbets Essentials Mini Oven with Rotisserie	35		Rear Spacer
DC285 - Nisbets Essentials Mini Oven with Rotisserie	36		Bushing Cord
DC285 - Nisbets Essentials Mini Oven with Rotisserie	37		Power Cord
DC285 - Nisbets Essentials Mini Oven with Rotisserie	38	AL042	Wire Rack
DC285 - Nisbets Essentials Mini Oven with Rotisserie	39	AL043	Food Tray
DC285 - Nisbets Essentials Mini Oven with Rotisserie	40	AL044	Crumb Tray
DC285 - Nisbets Essentials Mini Oven with Rotisserie	41	AL045	Rotisserie Handle
DC285 - Nisbets Essentials Mini Oven with Rotisserie	42	AL046	Food Tray Handle
DC285 - Nisbets Essentials Mini Oven with Rotisserie	43,44,45	AL047	Complete Rotisserie Fork
DC285 - Nisbets Essentials Mini Oven with Rotisserie	46	AL048	Line-Shaped Heatiig Element
DC285 - Nisbets Essentials Mini Oven with Rotisserie	47		Heat Insulation Plate
DC285 - Nisbets Essentials Mini Oven with Rotisserie	48		U Inner Plate
DC285 - Nisbets Essentials Mini Oven with Rotisserie	49	AL049	Rotisserie Fork Support
DC285 - Nisbets Essentials Mini Oven with Rotisserie	50		Heating Tube Shield
DC285 - Nisbets Essentials Mini Oven with Rotisserie	51		Left Hinge
DC285 - Nisbets Essentials Mini Oven with Rotisserie	52		Chain Wheel
DC285 - Nisbets Essentials Mini Oven with Rotisserie	53		Sliding Wheel Shaft
DC285 - Nisbets Essentials Mini Oven with Rotisserie	54		Panel
DC285 - Nisbets Essentials Mini Oven with Rotisserie	55		Quakeproof Cushion
DC285 - Nisbets Essentials Mini Oven with Rotisserie	56		Airproof Strip
DC285 - Nisbets Essentials Mini Oven with Rotisserie	57		Inner Glass Door
DC285 - Nisbets Essentials Mini Oven with Rotisserie	58,59,60	AL050	Door Handle