




Machine	Explode	Code	Description
Buffalo Food Warmer with Gantry - 3 x GN 1/1	1		Housing Assembly
Buffalo Food Warmer with Gantry - 3 x GN 1/1	2		Outer Lampshade Assembly
Buffalo Food Warmer with Gantry - 3 x GN 1/1	3		Inner Lampshade Assembly
Buffalo Food Warmer with Gantry - 3 x GN 1/1	4		Lamp Stand
Buffalo Food Warmer with Gantry - 3 x GN 1/1	5		Post Pole
Buffalo Food Warmer with Gantry - 3 x GN 1/1	6		Heating Tube Fixing Plate
Buffalo Food Warmer with Gantry - 3 x GN 1/1	7		Bottom Seal Plate
Buffalo Food Warmer with Gantry - 3 x GN 1/1	8	AS576	On/Off Switch
Buffalo Food Warmer with Gantry - 3 x GN 1/1	9	AS430	Thermostat
Buffalo Food Warmer with Gantry - 3 x GN 1/1	10	AS009	Knob
Buffalo Food Warmer with Gantry - 3 x GN 1/1	11	AS011	Knob Core
Buffalo Food Warmer with Gantry - 3 x GN 1/1	12	AS007	Heat Indicator
Buffalo Food Warmer with Gantry - 3 x GN 1/1	13	AS578	Acrylic Plate
Buffalo Food Warmer with Gantry - 3 x GN 1/1	14	AG570	Infrared Bulb
Buffalo Food Warmer with Gantry - 3 x GN 1/1	15	AS579	Ceramic Lamp Holder
Buffalo Food Warmer with Gantry - 3 x GN 1/1	16	AS580	Tempered Glass/Print Black
Buffalo Food Warmer with Gantry - 3 x GN 1/1	17	AS581	Mica Heating Plate
Buffalo Food Warmer with Gantry - 3 x GN 1/1	18		Screw
Buffalo Food Warmer with Gantry - 3 x GN 1/1	19	AS582	UK Power Cord
Buffalo Food Warmer with Gantry - 3 x GN 1/1	20	AL187	Power Cord Buckle
Buffalo Food Warmer with Gantry - 3 x GN 1/1	21	AK025	Terminal Block
Buffalo Food Warmer with Gantry - 3 x GN 1/1	22	AK017	Rubber Feet (Set 4)

Circuit Diagram

